

AIRTS EFFECTS

Business Card Mid Boost

Want to build a killer Mid Boost pedal out of your new business card? Follow the parts values below!

R1-1MEG

R2-100K

R3-10K

R4-1K

R5-4.7K

C1-4N7

C2-22N

C3-100PF

C4-100N

C5-100UF

C6-47UF

Q1-2N3904

D1-1N4001

If you want a more full range boost, change C1 & C2 to 47n or 100n. It will be much dirtier, but wont cut any bass.